



Item no. 601/738
Manufacturer's no. 1165010

Hazard symbol



Danger!, H318

Fabric Cleaner 500 ml



Information

Dimensions	9.5x24.5x6.5 cm
Pack size	24x10x7 cm
Net weight	520 g
Gross weight	650 g
Catalogue page	732

The fabric cleaner is the ideal solution for thorough cleaning and care of fabric covers, seat cushions and textiles for both indoor and outdoor use. The powerful formula effectively removes dirt, stains and other residues without damaging the material or altering the colours. This keeps fabrics hygienically clean and maintains their original freshness – perfect for camping furniture, car seats or household textiles.

Application: slightly dampen the area to be cleaned and spray the fabric cleaner evenly onto it. Allow the product to work for about 30 seconds before treating the surface with a soft brush or cloth. Repeat the process if necessary. Rinse the treated area thoroughly with water and let it dry completely – preferably in a well-ventilated room, but not in direct sunlight.

Specifications

Content	500 ml
---------	--------