



Item no. 301/253
Manufacturer's no. 704864



Hazard symbol



Danger!, H314, H318

Cleaner abtyCam green for Caravans and Motorhomes



Information

Dimensions	26x8 cm
Pack size	26x8x8 cm
Net weight	1 kg
Gross weight	1.2 kg
Catalogue page	407

The camping cleaner is suitable for many surfaces. It removes rain streaks and weather-related soiling as well as resins and insects. It can be used wherever the cleaner is needed when camping – both inside and outside. The cleaner can also be used for plastic garden furniture and acrylic glass.

Application:

For normal soiling, dilute up to a mixing ratio of 1:20. For stubborn soiling, apply pure with a sponge. Then rinse off with clear water.

Please note: when applying to aluminium, zinc and other light metals, rinse off IMMEDIATELY with clear water, otherwise there is a risk of tarnishing. Check all surfaces for material compatibility before use.

Specifications

Colour	transparent
Content	1 l