



**Item no. 323/698**

Manufacturer's no. 9620008169



## Battery Disconnecter NDS Battery Saver

**NDS** | **DOMETIC**

### Information

|                |                   |
|----------------|-------------------|
| Dimensions     | 121 x 50 x 108 mm |
| Pack size      | 12 x 9 x 5 cm     |
| Net weight     | 300 g             |
| Gross weight   | 400 g             |
| Catalogue page | 614               |

Battery Saver is an automatic battery disconnecter that constantly monitors the battery voltage and disconnects the battery from all devices when it falls below the critical value of 11 V. This protects the battery from power losses or serious damage caused by deep discharge. Additionally, it features a button for „manual mode,“ allowing you to turn off all devices at any time. Therefore, a manual restart or an automatic reset via a power source (e.g. alternator, 230 V charger or solar panel) is possible.

- Automatic (below 11 V) or manual battery disconnection
- Handling of up to 1200 W both at the input and output
- Operational indicator
- Automatic reconnection of the battery (when a power source is available)

### Specifications

|                 |      |
|-----------------|------|
| Nominal voltage | 12 V |
|-----------------|------|