



Item no. 301/095
Manufacturer's no. 16175

Slider Seal

THETFORD

Information

Pack size	17.4x13.4x2.1 cm
Net weight	66 g
Gross weight	66 g
Catalogue page	470

Slider seals of toilet cassettes become porous over time and should therefore be replaced regularly. To do this, simply remove the blade cover plate and pull the covers of the guide rails upwards. Then remove the screws and the cover plate to gain access to the slider seal. Remove the old slider seal, clean the area, insert the new slider seal with the thin flange side down and screw the cover plate back in place. Finally, spray the seal with a little Vaseline spray.

To slightly delay wear, simply clean the blade seal occasionally with a damp cloth.

For toilets up to 14/06/2000*.

* only for C-2, 3, 4

Specifications

Suitable for C2, C3, C4